


FLUANCE®

High Density Foam Speaker Isolation Pads
SP05

Positioning the Isolation Pads

Place the Isolation Pads under the Speakers



Setting the Desired Angle

Use the two foam wedges to pick between the different possible angles. The speakers should be angled so that the drivers are pointed at ear level.

Speaker Direction ➔

