

SAFETY INFORMATION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.


This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

IC STATEMENT


This device complies with Industry Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.




01 RECEIVER SET UP

ENSURE YOUR WS54 RECEIVER IS POWERED ON AND CONNECTED TO YOUR TV VIA HDMI INPUT




02 TV SET UP

SET YOUR TV/MONITOR TO THE WS54'S HDMI INPUT




03 PAIRING

PRESS THE "PAIRING BUTTON" ON THE FRONT OF THE RECEIVER



04 ACTIVATED

THE TV/MONITOR SCREEN WILL READ "PAIRING MODE ACTIVATED, PLEASE PRESS PAIRING BUTTON ON FRONT OF TRANSMITTER"



05 PAIR TRANSMITTER

PRESS THE "PAIRING BUTTON" ON THE FRONT OF THE TRANSMITTER. THE LED WILL NOW BEGIN TO FLASH RED



06 CONNECTED

ONCE THE TRANSMITTER HAS BEEN PAIRED, THE TV/MONITOR WILL READ "CONNECTED"

