
Headshell Installation Guide






Lead Wire Colors

Wire	Channel
White	Left (+)
Blue	Left (-)
Red	Right (+)
Green	Right (-)


Note: Cartridge installation video and guide are available at www.fluance.com/center

Headshell Installation

 Loosen the locking nut and remove the current headshell. It is recommended to store in a safe location with stylus protector on cartridge.



2. Insert the new headshell and tighten the locking nut until the headshell is secure.





Thank you for your purchase of this Fluance® product.

We hope you enjoy your experience.

Questions?
Give us a chance to help, we're just a click away.



Fluance.com/center



Fluance.com/support



Fluance.com/contact

Don't forget to register your product with us!

Fluance.com/registration/